

- 1. AT JAMBS (BOTH SIDES), EXTEND GALV. ESCUTCHEON OUT FAR ENOUGH TO END AT THE "HIGH" POINT ON THE VERTICAL CORRUGATION OF THE SIDING.
- 2. BOTH JAMBS HAVE SIMILAR CONDITIONS.



DUCT PENETRATION @ EXTERIOR WALL

SCALE : 1" = 1'-0"

A718-6 306

ARCHITECTURAL STANDARD DETAIL	DRAWN BY W.C. DATE	DETAIL TYPE WALL SCALE
DUCT PENETRATION @ EXTERIOR WALL	6/5/98 APPROVED BY	1"=1'-0" SHEET 306
UNIVERSITY OF CALIFORNIA - LAWRENCE BERKELEY NATIONAL LABORATORY	DATE	A718-6
FACILITIES DEPARTMENT	DRAWING FILE NAME A718-6 306	1